

ORDER OF INSTALLATION AND CONNECTION OF PARTS

(see Installation Instructions for details)

Installation methods:

SPC Panels: Installation on furring boards (included)

Wood Slats Ash: Finishing nails through face on the wall. Nails: #16, 2-2.5" long.

