

# ORDER OF INSTALLATION AND CONNECTION OF PARTS

---

(see Installation Instructions for details)

## Installation methods:

**SPC Panels:** Flat Installation (adhesive)

**Wood Slats Ash:** Finishing nails through face on the frame of furring boards (included). Nails: #16, 2-2.5" long.

