

INSTALLATION AND CONNECTION OF PARTS

(see Installation Instructions for details)

Installation methods:

SPC Panels: Flat Installation with adhesive

Wood Slats Ash: Finishing nails through face. Nails: #16, 2-2.5" long.

