

ORDER OF INSTALLATION AND CONNECTION OF PARTS

(see Installation Instructions for details)

Installation methods:

SPC Panels: Flat Installation on adhesive

Wood Slats Ash: Finishing nails through face (#16, 2-2.5" long).

