

ORDER OF INSTALLATION AND CONNECTION OF PARTS

(see Installation Instructions for details)

Installation methods:

SPC Panels: *Flat Installation on adhesive)*

Wood Panels: *Finishing nails (#16, 2-2.5" long).*

