

ORDER OF INSTALLATION AND CONNECTION OF PARTS

(see Installation Instructions for details)

Installation methods:

SPC Panels: Installation on double furring boards (included)

Cross-grooved Wood Panels: Clips and Screws (included). Nails: #16, 2-2.5" long.

