

ORDER OF INSTALLATION AND CONNECTION OF PARTS

(see Installation Instructions for details)

Installation methods:

SPC Panels: *Flat Installation (adhesive)*

Grooved Wood Slats: *Finishing nails (#16, 2-2.5" long)*

